

## Conversion Instructions for CFY TQ


This conversion is only required for **ProSim737** users, as ProSim737 has discontinued communication via the **FSUIPC interface**.

The conversion is necessary starting from **CFY Console version 2.0.0**.


1. Start your flight simulator and the CFY Console (your previous version of CFY Console).

- 2. Note the serial number of your TQ.**


It is shown in the top right corner of the CFY Console.





3. Press the trim down button on the yoke until the trim needle is at 0.




4. Close the CFY Console and the flight simulator. Turn off the CFY TQ and disconnect its power cable.
5. Remove the trim wheel on the First Officer's side.
6. Remove all mounting screws from the side panel on the First Officer's side, and take off the side panel.









7. Now manually turn the trim wheel on the Captain's side until the small steel pendulum drops off the threaded shaft.




8. It is best to store the pendulum on the floor in the TQ.



9. Reattach the side panel and trim wheel to the TQ
10. Reconnect the power cable to the TQ and switch the TQ on.
11. Start the flight simulator and ProSim737.
12. Register the Trim up and Trim down switches in ProSim737.



13. When using ProSim737, set the Trim Intensity slider to approximately this position. You can also adjust this position to your liking.



Germany 08.06.2025

